

FIG. 1




FIG. 2




FIG. 3A




FIG. 3B




FIG. 3C




FIG. 4A




FIG. 4B




FIG. 5




FIG. 6




FIG. 7




FIG. 8

9/15

209

QUICK TIPS SET-UP

VOLUME:

DISPLAY:

OFF	SOFT	MED	LOUD
OFF	DAY	NIGHT	AUTO

NEXT

FIG. 9

209

1001a	DRIVER'S VIEW	INSTRUMENT PANEL	DOOR CONTROLS	DASH CONTROLS
1001b	STEERING COLUMN CONTROLS	SEATS	DRIVETRAIN	INTERIOR LIGHTS
1001c	LOCKS	CLIMATE CONTROLS	AUDIO SYSTEM	STORAGE
1001d	DRIVING TIPS	CARE TIPS	UNDER HOOD	MAINTENANCE
1001e	INDEX			
	1001	1003	1005	1007

FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15




FIG. 16




FIG. 17




FIG. 18

1901

1903

1905	AIR CONDITIONING	LINK TO CLIMATE CONTROL SCREEN OF FIG. 15
	ANTI-LOCK BRAKE SYSTEM INDICATOR	LINK TO WARNING LIGHT OPTION #4 ON FUEL/TEMP SCREEN (NOT SHOWN)
	AUTOMATIC CLIMATE CONTROL	LINK TO CLIMATE CONTROL SCREEN OF FIG. 15
•	•	•
•	•	•
•	•	•
	CHARGING SYSTEM FAILURE INDICATOR	LINK TO CHARGING SYSTEM FAILURE OPTION 1309f (FIG. 13)
	CLIMATE CONTROL SYSTEM	LINK TO CLIMATE CONTROL SCREEN OF FIG. 15
	COOLING	LINK TO CLIMATE CONTROL SCREEN OF FIG. 15
	CRUISE CONTROL INDICATOR	LINK TO WARNING LIGHT OPTION #2 ON SPEEDOMETER SCREEN (NOT SHOWN)
	DEFOG/DEFROST	LINK TO CLIMATE CONTROL SCREEN OF FIG. 15
	DOOR AJAR INDICATOR	LINK TO WARNING LIGHT OPTION #7 ON FUEL/TEMP SCREEN (NOT SHOWN)
	DIRECTIONAL SIGNALS INDICATOR	LINK TO TURN SIGNAL/HAZARD WARNING OPTION 1201b (FIG. 12)
•	•	•
•	•	•
•	•	•

15/15

FIG. 19